



## Installing the Keyboard



### Programmable Keyboard

---

Step 1 Do you have an installation diskette? If yes, go to step 6. If no, go to step 2.

---

Step 2 Plug in the POS keyboard to the back of the computer.

---

Step 3 Go to [www.logiccontrols.com](http://www.logiccontrols.com) and click on the "Support & Downloads" tab.

Scroll down until you see a section called "Keyboards & Keypads" or click "Keyboards & Keypads" on the side panel.

Click the "For LK1600, LK1800, & LK8000" link. This will pop up a zip file to download.

Choose Save and save it to the desktop.

Also on the webpage, click the "Label Legend for LK16/18/8". This will pop up a zip file to download.

Choose Save and save it to the desktop (You will need this for the keyboard as there have been some keys programmed specifically for RV Logic).

Right-click on the zip file called LKUtility and click Extract All.

Go through the steps of the Extraction Wizard to unzip the file to the desktop.

Open the LKUtility folder on the desktop and double-click on the setup icon.

---

Click the START button to install. (If Hardware Installation screen pops



## Installing the Keyboard

---

up, click continue anyway).

Restart your computer.

---

Step 4 Double-click the LKWN icon.

Select the USB as the Port name (unless using a PS/2 cable, then choose PS/2) and click OK.

Go to the Template drop down menu and choose Load.

Go to the location of the LK8000 Layer1.tpl file that was sent to you by RV Logic (Not the one opened by the LKWN program) and open this file.

Go to the Configuration drop down menu and choose Write Into KB (DO NOT USE THE MOUSE AND/OR KEYBOARD DURING THE WRITING PROCESS!!!!)

Close the program when the above process has been completed.

---

Step 5 Test the keyboard by making sure that you are not in any windows and pressing the Sign In button. (If you don't have the labels already on your keyboard, it's the button in the top right hand corner of the keyboard).

RV Logic should start-up automatically. If this doesn't work, Repeat steps 14 - 20.

If this works you have successfully installed the keyboard and the RV Logic keyboard template file.

---

Step 6 Plug in the POS keyboard to the back of the computer.

---

Step 7 Double click on "Setup" program on the floppy disk.

Select destination folder and click "Install" to start the installation process. The default destination folder is "C:\Program Files\Logic Controls Utilities".

During the installation, skip any warning message dialog boxes by clicking "Yes" or "Continue".

---

When installation is completed, remove the floppy disk and reboot the



## Installing the Keyboard

---

computer.

Perform Step 4 and 5.

---

### The Keyboard Legend

`,[`]	J,[J]	1,[PAD1]	K7,[ShiftLevel1]
1,[1]	K,[K]	2,[PAD2]	]
2,[2]	L,[L]	3,[PAD3]	K8,[ShiftLevel2]
3,[3]	:[,;]	0,[PAD0]	]
4,[4]	",[']	.,[PAD.]	K9,Text[CR]
5,[5]	Enter,[Enter]	CR,[PADEnter]	K10,Logic
6,[6]	Shift,[Shift]	ESC,[ESC]	Controls\,
7,[7]	Z,[Z]	F1,[F1]	Inc.[CR]
8,[8]	X,[X]	F2,[F2]	K11,[PrintScreen]
9,[9]	C,[C]	F3,[F3]	K12,[ArrowUp]
0,[0]	V,[V]	F4,[F4]	K13,[Ctrl][P]
-,[-]	B,[B]	F5,[F5]	K14,Void
=,[=]	N,[N]	F6,[F6]	K15,Visa
\\,[\\]	M,[M]	F7,[F7]	K16,Sign in
BS,[Backspace]	<,[\,]	F8,[F8]	K17,Coupon
Tab,[Tab]	>,[.]	F9,[F9]	K18,Amex
Q,[Q]	?,[/]	F10,[F10]	K19,Check
W,[W]	Shift,[RightShift]	F11,[F11]	price
E,[E]	t]	F12,[F12]	K20,Check
R,[R]	Ctl,[Ctrl]	F13,HotKey	K21,Master
T,[T]	Win,[Win]	#1[CR]	K22,Return
Y,[Y]	Alt,[Alt]	F14,HotKey	K23,Cash
U,[U]	Space,[Space]	#2[CR]	K24,Discovery
I,[I]	Alt,[RightAlt]	F15,[ArrowLeft]	K25,Discount
O,[O]	Win,[RightWin]	F16,[ArrowDown]	K26,t
P,[P]	Men,[Menu]	F17,[ArrowRight]	K27,*
{,[{]	Ctl,[RightCtrl]	t]	K28,[CR]
},[}]	Num,[NumLock]	K1,[Win][E]	Locker,Layer1[
'	]	K2,[Ctrl][S]	CR]
CapsLk,[CapsLock]	-,[PAD-]	K3,[Ctrl][A]	
A,[A]	+,[PAD+]	K4,[Ctrl][C]	
S,[S]	7,[PAD7]	K5,[Ctrl][V]	
D,[D]	8,[PAD8]	K6,[Win][0F0][	
F,[F]	9,[PAD9]	Win][ArrowUp][	
G,[G]	4,[PAD4]	Enter]	
H,[H]	5,[PAD5]		
	6,[PAD6]		

#### RV LOGIC, INC.

3332 Southside Boulevard  
Jacksonville, Florida 32216

Ph: 904.998.4066

Fax: 904.998.4166

Website: <http://www.rvlogic.com>